

KARE
DESIGN

53205/53206 – Alarm clock Levin Gold /Silver
53207/53208 – Alarm clock Kian Black/Red

Gebrauchsanweisung

Zum Starten


Legen Sie 1 x AA-Batterie in der richtigen Position in das Batterie-Sortiment ein (+ und - polaritätsanzeigen).

Zeit- und Alarmeinstellung

Drehen Sie Knopf A [im Uhrzeigersinn], um die Uhrzeit einzustellen.
Drehen Sie den Knopf B [gegen den Uhrzeigersinn], um den Alarm einzustellen.

Aktivieren des Alarms

Zum Aktivieren des Alarmschalters schalten Sie den Alarmknopf auf ON.
Zum Abschalten des Alarms schalten Sie den Alarmknopf auf in die Position OFF.



KARE
DESIGN

53205/53206 – Alarm clock Levin Gold /Silver
53207/53208 – Alarm clock Kian Black/Red

Instruction manual

To start

Insert 1 x AA Battery into battery compartment in correct position (+ and - polarity indicators).

Time and alarm setting

Turn knob A (clockwise) to set the time.
Turn knob B (counter clockwise) to set the alarm.

Activate the alarm

To activate the alarm buzzer switch alarm knob to ON position.
To stop the alarm switch alarm knob to OFF position.

