







30 MIN




ASSEMBLY INSTRUCTION

83548 - TISCH BLACK MAGIC 220X100CM






A x16
M8x30



B x 16
Ø8.4x22x1.6








C x 16
Ø8.4x13x2




D x 1
V4x110





STEP 1



| | | | |
|--|---|---|---|
|  |  |  |  |
| A x 8 M8x25 | B x 8 Ø8.4x22x1.6 | C x 8 Ø8.4x13x2 | D x 1 V4x110 |

STEP 2



| | | | |
|--|---|---|---|
|  |  |  |  |
| A x 8 M8x25 | B x 8 Ø8.4x22x1.6 | C x 8 Ø8.4x13x2 | D x 1 V4x110 |