









84598 Tisch Symphony Eiche Rohstahl 180x90
84602 Tisch Symphony Eiche Rohstahl 200x100
84594 Tisch Symphony Eiche Schwarz 160x80
84599 Tisch Symphony Eiche Schwarz 180x90
84603 Tisch Symphony Eiche Schwarz 200x100

Parts.



Hardware-

Qty.

A.



Flat Washer

08

B.



Bolt

08


C.




Wrench

01


Step-1.









Step-2.




Step-3.




78521 - Ecksofa Oxford 3er Vintage Econo Links













Unscrew the outer ring to
change the bulb

